

MIT
Space
Engineering
Research
Center

Cost Averaging Techniques for Robust Control of Flexible Structural Systems

Nesbitt W. Hagood
Edward F. Crawley

Third Annual SERC Symposium
July 1, 1991

28 53
160330
p. 22
N93-28175

Outline

- Introduction
- Modeling of Parameterized Systems
- Average Cost Analysis
- Reduction of Parameterized Systems
- Static and Dynamic Controller Synthesis
- Examples

Problem Statement

- The problem is to design a controller that provides stability robustness over a set of plants described by real parameter uncertainty.
- This type of uncertainty is common in structural plants.
 - Uncertain stiffness
 - Uncertain damping
 - Uncertain modal parameters
- Stability examined in the context of the performance-robustness trade.

Background in Robust Control Synthesis

Bounding Methods

- Develop robustness analysis test
 - Lyapunov, Kharitonov, Small Gain, μ
- Incorporate analysis test into performance metric
 - modify Lyapunov equation or develop stability index
- Find controller which minimizes modified performance metric subject to constraints.

Sensitivity Methods

- Sensitize the cost to the uncertainties, then minimize.
- Multiplicative White Noise (MEOP): Hyland, Bernstein
- Cost Sensitivity Minimization: Skelton
- Multi-Model Techniques: Bryson, Li

Approach of This Work


- Examine cost averaged over a continuously parameterized set of plants.
- Derive analysis tools to determine approximations and bounds to the average cost.
- Apply these analysis tools to the problem of determining critical components and uncertainties.
- Apply these analysis tools to the problem of nonconservative robust controller design.

Modeling Notation

- A system $G(s)$ can be represented in state space notation as:

$$\begin{bmatrix} \dot{x} \\ z \\ y \end{bmatrix} = \begin{bmatrix} A & B_1 & B_2 \\ \hline C_1 & 0 & D_{12} \\ C_2 & D_{21} & 0 \end{bmatrix} \begin{bmatrix} x \\ w \\ u \end{bmatrix}$$

- The controlled system can be represented schematically:



Sets of Systems

- The set, Ω , of parameters is defined on the compact interval

$$\Omega = \left\{ \alpha : \alpha \in \mathbb{R}^r, -\delta_i^L \leq \alpha_i \leq \delta_i^U \quad i = 1, \dots, r \right\}$$
- The set \mathcal{G} of systems is parameterized as follows

$$\mathcal{G} = \{G(\alpha) \mid \alpha \in \Omega\}$$

– for structured parameter dependence

$$G(\alpha) = \left[\begin{array}{c|c} \frac{A_0 + \sum_{i=1}^r \alpha_i A_i}{C_1} & \frac{B_1 \quad B_{2_0} + \sum_{i=1}^r \alpha_i B_{2_i}}{D_{12}} \\ \hline C_{2_0} + \sum_{i=1}^r \alpha_i C_{2_i} & \frac{0 \quad D_{21}}{0} \end{array} \right]$$

The Average Cost

- The exact average cost is defined as the closed-loop \mathcal{H}_2 -norm (quadratic cost) averaged over the model set.

$$J = \int_{\Omega} \|G_{zw}(\alpha)\|_2^2 d\mu(\alpha)$$

- Finite average cost implies:
 - The closed-loop systems are stable $\forall \alpha \in \Omega$ except possibly at isolated points.
 - No closed-loop system can have eigenvalues with positive real parts.
- Controllers based on minimization of the average cost will guarantee stability without necessarily guaranteeing performance.

Average Cost Calculation

- The average cost is calculated

$$J = \text{tr} \left\{ \langle \tilde{Q}(\alpha) \rangle \tilde{C}^T \tilde{C} \right\}$$

- For each $\alpha \in \Omega$, $\tilde{Q}(\alpha)$ is given by

$$0 = \tilde{A}(\alpha)\tilde{Q}(\alpha) + \tilde{Q}(\alpha)\tilde{A}^T(\alpha) + \tilde{B}\tilde{B}^T$$

- The problem is how to compute the average solution to a parameterized Lyapunov equation.
 - Monte-Carlo
 - Direct Integration
 - Stochastic Operator Methods

Operator Decomposition

- Can utilize techniques from the field of wave propagation in random media and turbulence modeling.
- The parameterized Lyapunov equation can be decomposed into a nominal part and a parameter dependent part.

$$\tilde{A}(\alpha)\tilde{Q} + \tilde{Q}\tilde{A}^T(\alpha) + \tilde{B}\tilde{B}^T = 0$$

is equivalent to

$$\mathbf{L}_0[\tilde{Q}] + \mathbf{L}_1(\alpha)[\tilde{Q}] + \tilde{B}\tilde{B}^T = 0$$

$$\mathbf{L}_0[\tilde{Q}] = \tilde{A}_0\tilde{Q} + \tilde{Q}\tilde{A}_0^T$$

$$\mathbf{L}_1(\alpha)[\tilde{Q}] = \tilde{A}_1(\alpha)\tilde{Q} + \tilde{Q}\tilde{A}_1^T(\alpha)$$

- Two methods of computing the average: Perturbation Expansion and Dyson Equation.

Perturbation Expansion Approximation

- Perturbation expansion series can be approximated by retaining only the first two terms.
- The perturbation expansion approximate cost is given by

$$\tilde{Q}^P = \tilde{Q}^0 + \mathbf{A}(\mathbf{L}_0^{-1} \mathbf{L}_1(\alpha))^2 \tilde{Q}^0$$

$$J^P = \text{tr} \left\{ \tilde{Q}^P \tilde{C}^T \tilde{C} \right\}$$

where \tilde{Q}^B is the solution of

$$0 = \tilde{A}_0 \tilde{Q}^P + \tilde{Q}^P \tilde{A}_0^T + \tilde{B} \tilde{B}^T + \sum_{i=1}^r \sigma_i \left(\tilde{A}_i \tilde{Q}^i + \tilde{Q}^i \tilde{A}_i^T \right)$$

$$0 = \tilde{A}_0 \tilde{Q}^i + \tilde{Q}^i \tilde{A}_0^T + \sigma_i \left(\tilde{A}_i \tilde{Q}^0 + \tilde{Q}^0 \tilde{A}_i^T \right) \quad i = 1, \dots, r$$

- The equations for the perturbation expansion are related to those used in Skelton's cost sensitivity controller design method.
- The two sets of Lyapunov equations are coupled hierarchically and easily solved using standard techniques.

Bourret Approximation

- The Dyson Equation can be approximated by retaining only the first term of \mathbf{M} .

$$\tilde{Q}^B = \tilde{Q}^0 + \mathbf{A}(\mathbf{L}_0^{-1} \mathbf{L}_1(\alpha))^2 \tilde{Q}^B$$

- The Bourret approximate cost is given by

$$J^B = \text{tr} \left\{ \tilde{Q}^B \tilde{C}^T \tilde{C} \right\}$$


where \tilde{Q}^B is the solution of

$$\begin{aligned} 0 &= \tilde{A}_0 \tilde{Q}^B + \tilde{Q}^B \tilde{A}_0^T + \tilde{B} \tilde{B}^T + \sum_{i=1}^r \sigma_i \left(\tilde{A}_i \tilde{Q}^i + \tilde{Q}^i \tilde{A}_i^T \right) \\ 0 &= \tilde{A}_0 \tilde{Q}^i + \tilde{Q}^i \tilde{A}_0^T + \sigma_i \left(\tilde{A}_i \tilde{Q}^B + \tilde{Q}^B \tilde{A}_i^T \right) \quad i = 1, \dots, r \end{aligned}$$

- The Bourret equation represents an infinite series expansion for the approximate average solution.
- The cross-coupling complicates the solution procedure.
- Positive definite solution the Bourret equation guarantees stability over a set smaller than the design set.

Second Order System Example

- Consider the simple spring-mass-damper represented.




- The system has dynamics
$$\ddot{x}(t) + 2\zeta\omega\dot{x}(t) + \omega^2x(t) = bf(t)$$
- Let the natural frequency and damping ratios of the system be uniformly distributed uncertain parameters of the form

$$\begin{aligned}\omega^2 &= \omega_0^2 + \tilde{\omega}^2 & -\delta_{\omega^2} \leq \tilde{\omega}^2 \leq \delta_{\omega^2} \\ \zeta &= \zeta_0 + \tilde{\zeta} & -\delta_{\zeta} \leq \tilde{\zeta} \leq \delta_{\zeta}\end{aligned}$$

Cost vs. Model Uncertainty

- The cost as a function of the uncertain damping bound.



Robust Control Synthesis

- Fixed-form controllers

$$G_c = \left[\begin{array}{c|c} 0 & 0 \\ \hline 0 & D_c \end{array} \right] \text{ or } \left[\begin{array}{c|c} A_c & B_c \\ \hline C_c & 0 \end{array} \right]$$

- Controller Parameter Optimization Design Procedure

Step 1: Define cost based on exact average, bounding or approximating cost.

Step 2: Append the appropriate equation to the cost using a matrix of Lagrange multipliers.

Step 3: Determine the necessary conditions for optimality using matrix calculus.

Step 4: Minimize the cost numerically using necessary condition for gradient information.

Step 5: Evaluate the resulting controllers for stability and performance robustness.

Necessary Conditions

- For exact average cost minimization with static output feedback.

$$D_c = -R^{-1}B_2^T \langle \tilde{P}(\alpha) \tilde{Q}(\alpha) \rangle \langle \tilde{Q}(\alpha) \rangle^{-1}$$

where


$$0 = \tilde{A}(\alpha)\tilde{Q}(\alpha) + \tilde{Q}(\alpha)\tilde{A}^T(\alpha) + \tilde{B}\tilde{B}^T$$

$$0 = \tilde{A}^T(\alpha)\tilde{P}(\alpha) + \tilde{P}(\alpha)\tilde{A}(\alpha) + \tilde{C}^T\tilde{C}$$

- The necessary conditions have a form very similar to the necessary conditions derived for the static output feedback problem.
- Uncertainty couples the two parameterized Lyapunov equations.
- The same form is present with the approximations and bounds but with parameter independent equations.
- For dynamic output feedback the necessary condition comprise
 - three gain equations obtained by taking derivatives with respect to A_c, B_c , and C_c
 - two Lyapunov-based equations

Example 2: The Cannon-Rosenthal Problem

- Consider the four mass/spring/damper system with uncertain body one mass.




- The uncertain mass is represented

$$1/m_1 = 1/m_{1_0} + \tilde{m} \quad m_0 = 0.5 \quad |\tilde{m}| \leq \delta_m$$
- Spring and mass uncertainty treated by numerous researchers.


Pole-Zero Flip

- The problem was chosen because the plant zero and second mode change relative positions as the parameter is increased to $\tilde{m} = 0.6$
- The open loop u - y transfer functions for the Cannon-Rosenthal problem for $m_1 = 0.5$ (solid) and $m_1 = 0.25$ (dashed)




Achieved vs. Designed-for Robustness

- Achieved closed loop stability bounds as a function of the design bound, δ_m .




Cost vs. Parameter

- System closed-loop \mathcal{H}_2 -norm as a function of \tilde{m} , the deviation about $1/m_1$, for controllers designed Using $\delta_m = 0.1$.



Efficiency Plot

- Nominal cost as a function of the achieved stability bound.



Conclusions

- Have investigated a new class of controllers based on minimizing quantities related to the cost averaged over a parameterized set of plants.
- While possessing useful properties, the average cost based controllers were difficult to compute.
- The perturbation based controllers were easy to compute but performed well only at low uncertainty levels.
- The average bound designs were essentially equivalent to the worst case bound designs.
- The worst case bound performed as predicted but gave low efficiency due to conservatism.
- The Bourret approximation based designs were overall best in computability and efficiency.